



# ASSEMBLY INSTRUCTION FOR DINING CHAIR MODEL NO.: KSD-BS772C


1




2




3



4



5



A X1	B X4	C X1	D X1	
F X12	G X4	H X2	I X1	J X1
K X4	L X4	M X4	N X4	O X4
P X12	Q X1	R X1		