


Combination Key Safe Fitting Instructions

To open the key safe:

1. Slide shutter down to reveal dials
2. Rotate dials to the correct combination (factory setting is 0-0-0-0)
3. To open, push down button 1 shutter
4. When ready to close upset the dials to protect your combination
5. Close the shutter



Pic 1

To set your combination:

1. Open the key safe box (factory setting is 0-0-0-0)
2. Move the RESET button from position 'A' to position 'B', as shown in Pic 2
3. Turn the dials to desired combination
4. Move the RESET button from position 'B' back to position 'A'
5. The new combination is now set



Pic 2

RESET button

Important notes:

1. Keep the shutter closed for water resistance
2. It is recommended to rotate the dials regularly to maintain performance



Fitting instructions:

1. Inside the key safe are 5 holes for installation
2. Place the key safe in the desired position and mark, with a pencil
3. Using a suitable drill bit, drill holes into the marked positions
4. Place plastic expanded plugs [for masonry] into the holes that have just been drilled
5. Move the key safe into position and screw to fix

1 Drawing screw outline

2 Drilling holes

3 Nail into Expanded Plugs

4 Install the box by screws

Method 1: Installed on the wall